

NOTE:

- 1. TF500 BLOW-OFF HYDRANT BY THE KUPFERLE FOUNDRY COMPANY. SEE MANUFACTURER'S SPECIFICATION FOR FURTHER DETAILS.
- 2. SET TOP 1" ABOVE FINISHED GROUND IN UNPAVED AREAS. SET TOP FLUSH WITH PAVEMENT IN PAVED AREAS.

BLOW-OFF HYDRANT

STANDARD CONSTRUCTION DETAILS



SCALE: N.T.S.

DATED: SEP 2013

PLATE NUMBER:

W39